

eve button ⓘ

Get Started

Kako začnete?


Počnimo

①

Press Eve Button once to activate.

Za aktiviranje enkrat pritisnite gumb na napravi Eve.

Pritisnite gumb Eve jednom kako biste aktivirali.





❗

Customize Eve Button with the included labels and rubber feet.

Prilagodite gumb naprave Eve s priloženimi nalepkami in gumijastimi nogami.

Prilagodite gumb Eve s vključenim oznakama i gumenom stopicom.



②

Download the Elgato Eve app from the App Store.


Prenesite aplikacijo Elgato Eve iz trgovine App Store.

Preuzmite aplikaciju Elgato Eve iz trgovine aplikacijama App Store.

🔍 Elgato Eve



Download on the
App Store




③

Open the Elgato Eve app and tap Add Accessory. Eve will now guide you through the setup process.

Odprite aplikacijo Elgato Eve in se dotaknite Add Accessory (Dodaj dodatno opremo). Aplikacija Eve vas bo zdaj vodila skozi postopek namestitve.

Otvorite aplikacijo Elgato Eve i pritisnite Add Accessory. Eve će vas sada provesti kroz postupak postavljanja.

Add Accessory



If you have already set up another accessory, go to Settings in Eve to add Eve Button to your home.

Če ste že nastavili drugo dodatno opremo, pojdite na nastavitve Eve, da dodate napravo Eve Button v svoj dom.

Ako ste već instalirali drugi pribor, idite na postavke Eve kako biste dodali Eve Button na vašu početnu stranicu.

Hereby, Elgato Systems declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EC. The declaration of conformity is available at www.elgato.com/doc

Frequency range: 2402 - 2480 MHz

Max RF e.i.r.p power < 3dBm

Product: 10EAU9901 • Model: 20EAU9901 • Part: 51EAU9903

S tem družba Elgato Systems izjavlja, da je ta izdelek v skladu z bistvenimi zahtevami in drugimi ustreznimi določbami Direktive 2014/53/ES. Izjava o skladnosti je na voljo na www.elgato.com/doc

Obseg frekvence: 2402 - 2480 MHz

RF moč: < 3 dBm EIRP

Izdelek: 10EAU9901 • Model: 20EAU9901 • Del: 51EAU9903

Ovime tvrtka Elgato Systems izjavljuje da je ovaj uređaj u skladu s bitnim zahtjevima i drugim relevantnim odredbama Direktive 2014/53/EK. Izjava o sukladnosti je dostupna na www.elgato.com/doc

Raspon frekvencija: MHz: 2402 - 2480 MHz

Snaga radiofrekvencije: < 3 dBm EIRP


Proizvod: 10EAU9901 • Model: 20EAU9901 • Dio: 51EAU9903

Battery & Reset • Baterija in ponastavitev • Baterija i resetiranje

When replacing the battery, use your finger to open the enclosure. Insert a new CR2032 battery with the positive (+) side up, and push firmly while closing the cover.

Pri zamenjavi baterije odprite ohišje s prstom. Vstavite novo CR2032 baterijo s pozitivno (+) stranjo navzgor in trdno pritisnite, medtem ko zaprete pokrov.

Prilikom zamjene baterije, prstom otvorite kućište. Umetnite novu bateriju CR2032 s pozitivnom stranom (+) prema gore i čvrsto gurnite dok zatvarate poklopac.



Please keep your HomeKit setup code in a safe place. You need it to securely add Eve to your home, and nobody but you has a copy.

Prosimo, hranite kodo za namestitev HomeKit na varnem mestu. Potrebujete jo, da varno dodate Eve v svoj dom in nihče, razen vas nima kopije.

Čuvajte svoj kućni kod za instalaciju na sigurnom. Potreban vam je kako biste sigurno dodali aplikaciju Eve na svoju početnu stranicu i nitko osim vas nema kopiju.



eve button ①



Room • Soba • Prostor:

Notes • Opombe • Napomene:

.....

